
How to get the dynamic password

1. Click “Forget Password”




2. Choose the “Dynamic Password” to get the serial number



3. Please send us the serial number or take the photo, we will provide you with a dynamic password.



4. Fill the Dynamic Password with the code we sent you, then click Next Setp.



5. Modify the new password and save.

